

23336- Thornley Hall Farm

Surface Water Drainage Maintenance and Management Schedule:

Attenuation Basin

Maintenance Schedule	Required Action	Frequency
Regular Maintenance	Inspect and identify areas that are not operating correctly. If required take remedial action	Monthly for the first 3 months of operation then annually
	Recover debris from catchment surface area where it may cause risk to performance	Monthly
	Remove sediment and debris from pre-Basin system	Annually
Remedial Actions	Repair inlets/outlets/vents/overflows	As necessary
Monitoring	Inspect all inlets/outlets and upstream drainage system to ensure they are in good condition and operating as designed	Annually
	Survey inside of Basin for sediment and build up and remove if necessary	Every 5 years

Orifice Manhole

Maintenance Schedule	Required Action	Frequency
Regular Maintenance	Remove sediment and debris from Orifice chambers and upstream manholes	Monthly for first 12 months then 6 monthly
Remedial Actions	Replace or clean Orifice if performance deteriorates or failure occurs	As necessary
Monitoring	Check Orifice to ensure emptying is occurring	Quarterly and post high intensity storm event

Perforated Pipes

Maintenance Schedule	Required Action	Frequency
Regular Maintenance	Remove sediment and debris from pipes and manholes	Quarterly

Klargester Treatment Tank

Maintenance Schedule	Required Action	Frequency
Regular Maintenance	Remove sediment and debris from Klargester Treatment Tank	Monthly for first 12 months then 6 monthly
	Visual inspection for performance	6 monthly